

## SUPPLIES NEEDED:

**#6 Newspaper Holder**  
(part - NPH 6)

**NPH Straps - (2)**  
(part - NPH)

**Screwdriver**  
phillips

**Pliers or**  
**Small Wrench**



*(2 screws/2 nuts are included with the straps)*

## SINGLE SYSTEM INSTALLATION:

- 1 Attach number plate to mailbox. Bolt box to post, do not tighten.
- 2 Insert bolts through holes inside of box. Pass through NPH strap and tighten, ensuring strap catches NPH lip. Back of box and NPH should be flush.
- 3 Tighten all bolts, and continue installation.



## TWIN SYSTEM INSTALLATION:

- 1 Attach NPHs to each mailbox.
- 2 Bolt Twin T Bar to each NPH.
- 3 Insert S-Scroll into post and attach to hole in Twin T Bar.
- 4 Continue installation process.

